

### Challenger Widebody Stone Chip Guards

The wheel-well flanges and lower sills of the Dodge Challenger are prone to paint damage due to the constant pounding of tiny stones and other road debris found in normal driving. Our front Stone Chip Guards are designed to minimize this damage and protect your paint. Made from engineered ABS, each stone chip guard is laser-cut for a precise fit and tasteful appearance. Installation takes only minutes without the need to remove the wheels in most cases.

#### Tools you will need:

-- 9/32" Socket / Wrench

#### Front Stone Chip Guards –

1. Using your 9/32" Socket / Wrench remove the three O.E. fasteners from the wheel well liner as shown. The retaining hardware on the Challenger wheel well liner are butterfly style cage nuts and will remain in place.



2. The Stone Chip Guards are positioned with the molded offset spacers facing rearward on the car. These spacers allow the Stone Chip Guard to install flush with the wheel well.



3. Align the three holes of the Stone Chip Guards to the corresponding wheel liner retaining hardware. The butterfly cage nuts will move slightly to line-up with the holes. Install the three O.E. fasteners beginning with the top and working down. Caution should be used to prevent the inner butterfly cage nut from collapsing inward. For best results, begin turning the OE fasteners as you insert them to catch the cage nut threads.

**Do not overtighten.**



4. Congratulations...You are done! The finished installation will help to protect your Challenger for years to come.

